

# CNH 2140 PIVOT-TRANSPORT PLANTER

12/23, 12/24, 16/31, 16/32, and 24 Row

<i>Model No.'s to Order for each planter configuration</i>		<i>Quantity to order for each planter</i>		
		<b>12 R N 30"</b> 12 and 23, 24	<b>16 R N 30"</b> 16 and 31,32	<b>24 R 22"</b>
<b>UNIT MOUNT FERT COULTER</b>	<b>NOT AVAILABLE</b>			
<b>LIQUID FERT. COULTER FRAME MOUNTED</b>	<b>NOT AVAILABLE</b>			
<b>DRY FERT. COULTER FRAME MOUNTED</b>	<b>NOT AVAILABLE</b>			
<b>2960 UNIT MOUNTED CONSERVATION COULTERS ONLY</b>	2960-020-MW (unit coulter only with 25 wave blade)	<b>12 or 23,24</b>	<b>16 or 31,32</b>	<b>24</b>
<b>CLEAN UP CREW ONLY 30" Spacing Minimum</b>	2940-003B Pneumatic assembly or 2967-053A Screw Adjust residue manager or 2967-097B Short titan residue manager or 2967-106A (13" steel wheel)***&	<b>12</b>	<b>16</b>	<b>N/A</b>
<b>COMBINATION UNIT</b>	2967-008A Titan (for use with 2960-020 coulter) or 2940-004B Pneumatic assembly narrow row	<b>12</b>	<b>16</b>	<b>N/A</b>
<b>15"/20" SPACING ONLY</b>	or 2967-014B Short / Narrow UNT or 2967-036A Narrow row residue manager	<b>23/24</b>	<b>31/32</b>	<b>24</b>
<b><u>DOUBLE COULTERS</u> Fertilizer</b>	<b>NOT AVAILABLE</b>	<b>N/A</b>	<b>N/A</b>	<b>N/A</b>