

JD 1790 & 1795 DOUBLE CROP SOYBEAN SEEDING SYSTEM

Recommendations made here are NOT to be used in No-till cornstalk residue.

Use of Residue Managers in 15" Rows for planting soybeans directly into harvested wheat stubble.

Coulter/Residue Manager Combination - 1790 planter must be equipped with ordering code 5415. Included in code 5415 are long parallel arms, long drive cables, vacuum hoses, seed delivery hoses and down force spacers.

Model No's to Order for each planter configuration

		Quantity to order for each planter	
		23/24R (15")	31/32R (15")
2960 UNIT MOUNTED CONSERVATION COULTERS ONLY	2960-034 Coulter w/ U.N.T. bracket ** or 2960-127 (coulter only)**	23/24	31/32
	2940-001B Pneumatic assembly or 2940-002B Pneumatic assembly narrow row or 2967-013B Short Narrow U.N.T. or 2967-028A Universal unit mounted residue manager or 2967-029B Short U.N.T. or 2967-048A Narrow row unit mounted Residue Manager or 2967-052A Screw Adjust^ or 2967-054A Narrow Row Screw Adjust^ or 2967-056A Narrow Row Screw Adjust (Long arm)^ or 2967-057A Screw Adjust (Long arm)^ or 2967-081A (R.M. attachment for JD tool hanger)	23/24	31/32
CLEAN UP CREW ONLY			
Residue Manager Combinations	2967-007A U.N.T. Residue Manager Kit or 2967-042B Titan Residue Manager for JD Coulter or 2967-115A (for use with 2960-127 coulter) or 2967-070 (Quick adjust) Optional	23/24	31/32

**Blade Choices refer to price book.

^ Quantity to order varies depending on which parallel arm "ordering code" the planter is equipped