

KINZE SERIES 2600/3600 TWINLINE PLANTER

8 Row Wide, 12 Row and 16 Row with or without pusher row units

Model No.'s to Order for each planter configuration

		Quantity to order for each planter		
		8/15 R W	12/23 R N/W	16/31 R N
Unit Mounted	2959-003 (2" offset fert. injection)	8	12	16
Liquid Fertilizer Coulters	w/ 2967-180B (Residue manager for 2959-003)	4	6	6
	2975-188 (set back bracket)			
	or 2962-003A and 2962-004A RUMDDFO			
	w/ 2962-005B (Residue Manager for 2962-003A/-004A) Optional			
	or 2968-021B-R-LB/-L-LB Row Unit mount			
	& 2968-132 10" wheel assembly			
2960 UNIT MOUNTED CONSERVATION COULTERS ONLY	2960-033 Coulters w/ U.N.T. bracket (Kinze)**	8 or 15	12 or 23	16 or 31
	or 2960-127 (unit coulters only)**			
CLEAN UP CREW ONLY	2940-005B Pneumatic assembly	8 or 15	12 or 23	16 or 31
	or 2940-006B Pneumatic assembly			
	or 2967-013B Short / Narrow UNT			
	or 2967-028A Universal unit mounted residue manager			
	or 2967-029B Short UNT			
	or 2967-052A Screw Adjust (1993 to current)			
	or 2967-054A Narrow row Screw Adjust (1993 to current)			
	or 2967-056A Narrow row Screw Adjust (pre- 1993)			
or 2967-057A Screw Adjust (pre -1993)				
Combination Attachment	2967-007A U.N.T. (use with 2960-033 coulters)	8 or 15	12 or 23	16 or 31
	or 2967-035A Titan Universal			
	or 2967-115A (for use with 2960-127 coulters)			
	2967-070 (Quick adjust) Optional			
	2975-188 (set back bracket)*** Required	4	6	6

** See the price book for blade choices.

*** Must be used on center rows when using Combination attachments

NOTE - DUE TO MANUFACTURING CHANGES IN PLANTER, SOME ATTACHMENTS MAY NOT BE USED OR MODIFIED.