

CASE/IH 800-900/950-955/1200 NEW HOLLAND SP480 TRAILING PLANTER

Equipped with 2" x 6" fertilizer frame and tanks plus Endwise Transport
8 Row Narrow, 8 Row Wide, and 12 Row Narrow

Model No.'s to Order for each planter configuration			Quantity to order for each planter		
			8 R N	8 R W	12 R N
LIQUID FERT. COULTERS ONLY	2995-017 or 2995-002-L and 2995-002-R^	Choose either model	8 or 4 and 4	8 or 4 and 4	12 or 6 and 6
DRY FERT. COULTERS ONLY	NOT AVAILABLE				
2960 UNIT MOUNTED CONSERVATION COULTERS ONLY	2960-020 (unit couler only) or 2960-020-MW (unit couler only with 25 wave blade)	Choice of one style	8	8	12
CLEAN UP CREW ONLY	2965-021 (13" Notched blade)& or 2965-023 Screw Adjust Trashmaster or 2965-106 (12" solid blade)& or 2967-014 Short / Narrow UNT or 2967-036 Narrow row residue manager or 2967-044-L or R Notched Screw Adjust or 2967-053 Screw Adjust or 2967-055 Narrow Row Screw Adjust or 2967-097 Short titan residue manager or 2967-106 (13" steel wheel)***& 2961-011 Cut-n-Move		8	8	12
COMBO ATTACHMENT	2967-008 Titan (for use with 2960-020 couler)		8	8	12
FRAME MOUNTED COULTERS ONLY	2999-132 (basic couler ass'y 2x6)**	Choice of blade	8	8	12
DOUBLE COULTERS					
2 LIQUID FERT. COULTERS	2995-002-L (fits 2" x 6" bar) ^		8	8	12
	2995-002-R (fits 2" x 6" bar) ^		8	8	12
	3011-302 (5" offset Shank)***	Required	8	8	12
	2920-305 (swivel collar)****	Required	2	2	3
1 NO-TILL / 1 FERT. COULTERS	2999-132 (basic couler ass'y 2x6)**	Choice of blade	8	8	12
	2995-002-L (Liquid fert. fits 2" x 6" bar) ^		8	8	12
	3011-302 (5" offset Shank)***	Required	8	8	12
	2920-305 (swivel collar)****	Required	2	2	3
2 NO-TILL COULTERS	2999-132 (basic couler ass'y 2x6)**		16	16	24
	3011-302 (5" offset Shank)***	Required	8	8	12
	2920-305 (swivel collar)****	Required	2	2	3
1 LIQUID FERT. AND	2995-002-L and 2995-002-R^		4 and 4	4 and 4	6 and 6
	2960-020 (unit couler only) or 2960-020-MW (unit couler only with 25 wave blade)	Choice of one style	8	8	12
1 COMBO UNIT	2967-008 Titan (for use with 2960-020 couler)		8	8	12

** See the price book for choice of blades.

*** 5" offset shank is a replacement for the straight shank which is standard on the couler. Order the part # listed and restock the same quantity of part # 3010-303 (straight shank)

**** The swivel collar is required for the two coulters which must be rotated to clear the transport wheel.

& First year production of 800 planter requires Case/IH unit mount plate or modification of the planter unit.

^ Fertilizer placements available are : L & R = left & right standard rear knife, LS & RS = left & right side profile knife

LIHD & RIHD = left & right hand injection (tips not included). See Glossary for illustrations.

CASE/IH 800-900/950-955/1200 NEW HOLLAND SP480 TRAILING PLANTER

Equipped with Endwise Transport and no other options

8 Row Wide and 12 Row Narrow

<i>Model No.'s to Order for each planter configuration</i>			<i>Quantity to order for each planter</i>	
			8 R N	12 R N
LIQUID FERT. COULTERS ONLY	2995-017	Choose either model	8 or 4 and 4	12 or 6 and 6
	or 2995-006-L and 2995-006_R^			
	2970-179 (front bar mount kit)	Required	2	2
	2970-133 (scraper)	Optional	8	12
DRY FERT. COULTERS ONLY	NOT AVAILABLE			
2960 UNIT MOUNTED CONSERVATION COULTERS ONLY	2960-020 (unit coulter only)	Choice of blade style	8	12
	or 2960-020-MW (unit coulter only with 25 wave blade)			
CLEAN UP CREW ONLY	2965-021 (13" Notched blade)		8	12
	or 2965-023 Screw Adjust Trashmaster			
	or 2965-106 (12" solid blade)			
	or 2967-014 Short / Narrow UNT			
	or 2967-036 Narrow row residue manager			
	or 2967-044-L or R Notched Screw Adjust			
	or 2967-053 Screw Adjust residue manager			
	or 2967-055 Narrow row Screw Adjust residue manager			
or 2967-097 Short titan residue manager				
COMBO ATTACHMENT	2961-011 Cut-n-Move		8	12
	2967-008 Titan (for use with 2960-020 coulter)			
Frame Mounted Coulters Only	2999-106 (basic coulter ass'y 2.5" sq)**	Choice of blade	8	12
	2970-179 (front bar mount kit)		2	2

** See the price book for blade choices.

**** The swivel collar is required for the two coulters which must be rotated to clear the transport wheel.
(see the note below and the illustration on page 10)

& First year production of 800 planter requires Case/IH unit mount plate or modification of planter unit.

^ Fertilizer placements available are: L & R = left & right standard rear knife, LS & RS = left & right side profile knife
LIHD & RHID = left & right hand injection (tips not included). See glossary for illustrations.

NOTE - IF FERTILIZER FRAME OR OPTIONAL FRAME MOUNTED COULTERS ARE USED IN CONJUNCTION AND THEY ARE MOUNTED IN THE CENTER OF THE ROW, FERTILIZER COULTERS CAN ONLY BE MOUNTED 4" OR FARTHER FROM THE ROW.

NOTE - ON PLANTERS EQUIPPED WITH DOUBLE COULTERS - BEFORE TRANSPORTING, 2 COULTERS MUST BE ROTATED TO CLEAR TRANSPORT WHEEL.

CASE/IH 800-900/950-955/1200 NEW HOLLAND SP480 TRAILING PLANTER

Equipped with Endwise Transport and no other options

8 Row Wide and 12 Row Narrow

<i>Model No.'s to Order for each planter configuration</i>		<i>Quantity to order for each planter</i>	
		8 R W	12 R N
DOUBLE COULTERS	2995-006-L^	8	12
2 LIQUID FERT. COULTERS	2995-006-R^	8	12
	2970-179 (front bar mount kit) Required	2	2
	2920-305 (swivel collar)**** Required	2	3
1 NO-TILL / 1 FERT. COULTERS	2999-106 (basic coulters ass'y 2.5" sq)** Choice of blade	8	12
	2995-046-L (Liquid fert. fits 2.5" sq bar) ^	8	12
	2970-179 (front bar mount kit) Required	2	2
	2920-305 (swivel collar)**** Required	2	3
2 NO-TILL COULTERS	2999-106 (basic coulters ass'y 2.5" sq)** Choice of blade	16	24
	3011-302 (5" offset Shank)*** Required	8	12
	2970-179 (front bar mount kit) Required	2	2
	2920-305 (swivel collar)**** Required	2	3
1 LIQUID FERT. AND 1 COMBO UNIT	2995-046-L and 2995-046-R^	4 and 4	6 and 6
	2970-179 (front bar mount kit) Required	2	2
	2920-305 (swivel collar)**** Required	2	3
	2960-020 (unit coulters only) Choice of		
	or 2960-020-MW (unit coulters only with 25 wave blade) one style	8	12
	2967-008 Titan (for use with 2960-020 coulters)	8	12

** See the price book for blade choices.

**** The swivel collar is required for the two coulters which must be rotated to clear the transport wheel.

(see the note below and the illustration on page 10)

& First year production of 800 planter requires Case/IH unit mount plate or modification of planter unit.

^ Fertilizer placements available are : L & R = left & right standard rear knife, LS & RS = left & right side profile knife

LIHD & RIHD = left & right hand injection (tips not included). See Glossary for illustrations.

NOTE - IF FERTILIZER FRAME OR OPTIONAL FRAME MOUNTED COULTERS ARE USED IN CONJUNCTION AND THEY ARE MOUNTED IN THE CENTER OF THE ROW, FERTILIZER COULTERS CAN ONLY BE MOUNTED 4" OR FARTHER FROM THE ROW.

NOTE - ON PLANTERS EQUIPPED WITH DOUBLE COULTERS - BEFORE TRANSPORTING, 2 COULTERS MUST BE ROTATED TO CLEAR TRANSPORT WHEEL.