

JD 7000 FRONT FOLD DRAWN PLANTER

Equipped with John Deere 2.5" fert. Bar

Includes Flex Frame Models

Model No.'s to Order for each planter configuration

Quantity to order for each planter

		8 R W	12 R N	16 R N	
	2995-017	8 or	12 or	16 or	
LIQUID FERT. COULTERS ONLY	2995-014 and 2995-015 T.O.W opener (no bar kit required) or 2995-005-R and 2995-005-L (12 5/8" shank)^ Note: Reinforcing brackets are not required.	4 and 4	6 and 6	8 and 8	
DRY FERT. COULTERS ONLY	2995-025-R (3" offset shank)^	8	12	16	
Unit Mounted Liquid Fertilizer Coulters	2959-003 (2" offset fert. injection) 2967-180 (Residue manager for 2959-003) or 2961-012 Cut-n-Feed or 2962-001 and 2962-002 RUMDDFO or 2963-001 L & R Challenger	8	12	16	
2960 UNIT MOUNTED CONSERVATION COULTERS ONLY	2960-015 (with spring kit)** or 2960-031 Universal Unit Coulters (JD 7000) or 2960-033 CLTR W/U.N.T. BRKT (JD 7000) or 2960-127 (coulters only)**	Choice of blade	8	12	16
CLEAN UP CREW ONLY	2960-126 (spring kit only) or 2965-015 (12" solid blade) or 2965-020 (13" notched blade) or 2967-009 Screw adjust residue manager UNT or 2967-013 Short Narrow U.N.T. or 2967-015 (13" steel wheel) or 2967-028 Universal unit mounted residue manager or 2967-029 Short UNT or 2967-048 Narrow row unit mounted residue manager or 2967-056 Narrow Screw Adjust residue manager or 2967-057 Screw Adjust Residue manager or 2967-094 L & R Notched disc, universal mount	8	12	16	
COMBO ATTACHMENT	2961-010 Cut-n-Move 2967-007 U.N.T. Residue Manager Kit or 2967-035 Titan Universal or 2967-115 (for use with 2960 coulters) 2967-070 (Quick adjust)	Optional	8	12	16
FRAME MOUNTED COULTERS ONLY	2999-020(basic coulters ass'y 12 5/8" shank)	Choice of blade	8	12	16

** See the price book for blade choices.

***This kit may be replaced by welding a short piece of a 2 1/2" sq. bar under the tongue along with 2975-175 (8 row) or 2975-176 (12 row) will be required - however Yetter is not responsible for any damage caused by doing so.

Also on Flex models center front bar must be cut in center.

***Fertilizer Coulters can only be mounted 3" or farther from the row.

\$See price book for one fertilizer wheel options for 2968

^ Fertilizer placements available are : L & R = left & right standard rear knife, LS & RS = left & right side profile knife

LIHD & RIHD = left & right hand injection (tips not included). See Glossary for illustrations.

Continued on page 8

JD 7000 FRONT FOLD DRAWN PLANTER

DOUBLE COULTERS

2 LIQUID FERT. COULTERS ONLY	2995-035-L and 2995-035-R^		8 and 8	12 and 12	16 and 16
	2975-172 (front bar mount kit)***	Required	1	1	1
	6005-104(reinforcing bracket)	Required	2	4	4
1 LIQUID / 1 DRY FERT. COULTERS	2995-025-L and 2995-035-R^		8 and 8	12 and 12	16 and 16
	2975-172(front bar mount kit)***	Required	1	1	1
	6005-104(reinforcing bracket)	Required	2	4	4
1 NO-TILL / 1 FERT. COULTERS	2999-135 (basic coulter ass'y 2.5"sq 3"offset)**	Choice of blade	8	12	16
	2995-035-L (Liquid Fert. Coulter)^		8	12	16
	or 2995-025-L (Dry Fert. Coulter)^				
	2975-172(front bar mount kit)***	Required	1	1	1
	6005-104(reinforcing bracket)	Required	2	4	4
2 NO-TILL COULTERS	2999-135 (basic coulter ass'y 2.5" sq 3" offset)**	Choice of blade	16	24	32
	2975-172(front bar mount kit)***	Required	1	1	1
	6005-104(reinforcing bracket)	Required	2	4	4
1 LIQUID FERTILIZER AND 1 COMBO UNIT	2960-015 (with spring kit)**		8	12	16
	or 2960-033 CLTR W/U.N.T. BRKT (JD 7000)				
	2967-007 U.N.T. Residue Manager Kit				
	or 2967-115 (for use with 2960 coulter)		8	12	16
	or 2967-035 Titan Universal				
	2995-005-R and 2995-005-L (12 5/8" shank)^		4 and 4	6 and 6	8 and 8
	2975-188 (Set back bracket)	Required	8	12	16
COMBO UNIT/ 1 JD FERT. COULTER	2960-015 (with spring kit)**		8	12	16
	or 2960-033 CLTR W/U.N.T. BRKT (JD 7000)				
	2967-007 U.N.T. Residue Manager Kit				
	or 2967-115 (for use with 2960 coulter)		8	12	16
	or 2967-035 Titan Universal				
	2975-188(Set back bracket)	Required	8	12	16

** See the price book for blade choices.

***This kit may be replaced by welding a short piece of a 2 1/2" sq. bar under the tongue along with 2975-175 (8 row) or 2975-176 (12 row) will be required - however Yetter is not responsible for any damage caused by doing so.

Also on Flex models center front bar must be cut in center.

***Fertilizer Coulters can only be mounted 3" or farther from the row.

\$See price book for one fertilizer wheel options for 2968

^ Fertilizer placements available are : L & R = left & right standard rear knife, LS & RS = left & right side profile knife

LIHD & RIHD = left & right hand injection (tips not included). See Glossary for illustrations.