

JD 7200 WING FOLD PLANTER

Equipped with no other options
8 Row Wide and 12 Row Narrow

<i>Model No.'s to Order for each planter configuration</i>		Quantity to order for each planter	
		8 R W	12 R N
LIQUID FERT.	2995-014 and 2995-015 T.O.W. opener (no bar kit required) or 2995-010-L and 2995-010-R (16" shank) ^	4 and 4	6 and 6
COULTERS ONLY	2975-135 (mounting kit) Required		1
	2975-136 (mounting kit) Required	1	
Unit Mounted Liquid Fertilizer Coupler	2959-003 (2" offset fert. injection)	8	12
	2967-180 (Residue Manager for 2959-003)	8	12
	2975-189 (Set back bracket) Required	2	2
	or 2961-012 (Cut-n-feed) or 2962-001 and 2962-002 RUMDDFO or 2963-001 L & R Challenger		
2960 UNIT MOUNTED CONSERVATION COULTERS ONLY	2960-015 (with spring kit)** Choices of blade		
	or 2960-032 Unit couler		
	or 2960-034 Couler w/ U.N.T. bracket	8	12
	or 2960-127 (couler only)** or 2960-126 (spring kit only)		
CLEAN UP CREW ONLY	2965-015 (12" solid blade)		
	or 2965-020 (13" Notched Blade)		
	or 2965-022 Screw Adjust Trashmaster		
	or 2967-009 Screw adjust residue manager UNT (long arm)		
	or 2967-013 Short Narrow U.N.T.		
	or 2967-015 (13" steel wheel)		
	or 2967-028 Universal unit mounted residue manager		
	or 2967-029 Short U.N.T.	8	12
	or 2967-048 Narrow row unit mounted Residue Manager		
	or 2967-049 Screw Adjust Short UNT		
	or 2967-052 Screw Adjust or 2967-054 Narrow row screw adjust or 2967-081 (R.M. attachment for JD tool hanger) or 2967-092 L & R Notched disc, for JD tool hanger or 2967-093 L & R Notched disc screw adjust or 2967-094 L & R Notched disc, universal mount		
COMBO ATTACHMENTS	2961-010 Cut-n-Move		
	or 2967-007 U.N.T. Residue Manager Kit		
	or 2967-035 Titan Universal		
	or 2967-042 Titan Residue Manager for JD Couler		
	or 2967-043 Titan Screw adjust residue manager for JD Couler		
	or 2967-051 For use with JD Couler		
or 2967-115 For use with 2960-015 couler	8	12	
2967-070 (Quick adjust kit) Optional	8	12	

**For Blade choices refer to price book.

^ Fertilizer placements available are : L & R = left & right standard rear knife, LS & RS = left & right side profile knife
LIHD & RIHD = left & right hand injection (tips not included). See glossary for illustrations.

NOTE - DRY FERTILIZER COULTERS AND DOUBLE COULTER COMBINATIONS NOT AVAILABLE.

JD 7200 WING FOLD PLANTER

Equipped with Planter Unit Mounted Conservation Coulters, The Clean Up Crew,
or with John Deere Disk Furrowers

8 Row Wide and 12 Row Narrow

<i>Model No.'s to Order for each planter configuration</i>	Quantity to order for each planter	
	8 R W	12 R N
LIQUID FERTILIZER 2995-014 and 2995-015 T.O.W. opener (no bar kit required) COULTERS	4 and 4	6 and 6

**For Blade choices refer to price book.

^ Fertilizer placements available are : L & R = left & right standard rear knife, LS & RS = left & right side profile knife
LIHD & RIHD = left & right hand injection (tips not included). See glossary for illustrations.

NOTE - DRY FERTILIZER COULTERS AND DOUBLE COULTER COMBINATIONS NOT AVAILABLE.