

# JD 1770 NT FRONT FOLD PLANTER

Equipped with no other options  
8 Row Wide and 12 Row Narrow

<i>Model No.'s to Order for each planter configuration</i>		Quantity to order for each planter		
		12 R 30"	16 R 30"	24 R 30"
<b>Unit Mounted Liquid Fertilizer Coulters</b>	2995-014 and 2995-015 T.O.W. opener (no bar kit required)			
	or 2959-003 (2" offset fert. injection)			
	2967-180 (Residue Manager for 2959-003)	12	16	24
	or 2961-012 (Cut-n-feed)			
	or 2962-001 and 2962-002 RUMDDFO or 2963-001 L & R Challenger			
<b>2960 UNIT MOUNTED CONSERVATION COULTERS ONLY</b>	2960-015 (with spring kit)** Choices of blade			
	or 2960-032 Unit coulters			
	or 2960-034 Coulters w/ U.N.T. bracket	12	16	24
	or 2960-127 (coulters only)** or 2960-126 (spring kit only)			
<b>CLEAN UP CREW ONLY</b>	2965-015 (12" solid blade)			
	or 2965-020 (13" Notched Blade)			
	or 2965-022 Screw Adjust Trashmaster			
	or 2967-009 Screw adjust residue manager UNT (long arm)			
	or 2967-013 Short Narrow U.N.T.			
	or 2967-015 (13" steel wheel)			
	or 2967-028 Universal unit mounted residue manager			
	or 2967-029 Short U.N.T.	12	16	24
	or 2967-048 Narrow row unit mounted Residue Manager			
	or 2967-049 Screw Adjust Short UNT			
	or 2967-052 Screw Adjust			
	or 2967-054 Narrow row screw adjust			
	or 2967-081 (R.M. attachment for JD tool hanger)			
or 2967-092 L & R Notched disc, for JD tool hanger				
or 2967-093 L & R Notched disc screw adjust				
or 2967-094 L & R Notched disc, universal mount				
<b>COMBO ATTACHMENTS</b>	2961-010 Cut-n-Move			
	or 2967-007 U.N.T. Residue Manager Kit			
	or 2967-035 Titan Universal	12	16	N/A
	or 2967-042 Titan Residue Manager for JD Coulters			
	or 2967-043 Titan Screw adjust residue manager for JD Coulters	12	16	24
	or 2967-051 For use with JD Coulters			
or 2967-115 For use with 2960-015 coulters	8	10	12	
2967-070 (Quick adjust kit) Optional				

**NOTE: Some fertilizer coulters and row unit combinations result in the fertilizer opener offset from 4"-6" of the center line of the true V-opener.**

\*\*For Blade choices refer to price book.

^ Fertilizer placements available are : L & R = left & right standard rear knife, LS & RS = left & right side profile knife

LIHD & RIHD = left & right hand injection (tips not included). See glossary for illustrations.

Continued on page 24

# JD 1770 NT FRONT FOLD PLANTER

<i>Model No.'s to Order for each planter configuration</i>		<i>Quantity to order</i>		
		<i>12 R 30"</i>	<i>16 R 30"</i>	<i>24 R 30"</i>
<b>COULTER / RM COMBO</b>	2960-034 Coulter w/ U.N.T. bracket			
<b>W/ JD LIQ FRM MT</b>	or 2960-127 (coulters only)**			
	Choice of blade			
<b>FERT COULTERS</b>	or 2967-007 U.N.T. Residue Manager kit			
	or 2967-042 Titan Residue Manager for JD Coulter	<b>12</b>	<b>16</b>	<b>24</b>
	or 2967-043 Titan Screw adjust residue manager for JD Coulter			
	or 2967-051 For use with JD Coulter			
	or 2967-115 (for use with 2960-015)			
	2967-070 (Quick adjust)			
	<b><i>Long parallel arm option package from planter manufacturer is required</i></b>			
	2995-L and 2995-R	<b>9L and 1R</b>	<b>13L and 1R</b>	<b>22L and 2R</b>
<b>1 Liquid Fertilizer and Combo Unit Only</b>	2995-005-L and 2995-005-R	<b>1 and 1</b>	<b>1 and 1</b>	
	2995-170 (front bar kit) Required	<b>1</b>	<b>1</b>	
	2995-174 Bar Kit, JD 1770 NT, 24 Row '05			<b>1</b>
	<b><i>Long parallel arm option package from planter manufacturer is required</i></b>			
	or 2960-034 Coulter w/ U.N.T. bracket			
	or 2960-127 (coulters only)	<b>12</b>	<b>16</b>	<b>24</b>
	2967-007 U.N.T. Residue Manager kit			
	or 2967-042 Titan Residue Manager for JD Coulter	<b>12</b>	<b>16</b>	<b>24</b>
	or 2967-043 Titan Screw adjust residue manager for JD Coulter			
	or 2967-051 (for use with JD Coulter)			
	or 2967-115 (for use with 2960-015)			
	<b><i>Long parallel arm option package from planter manufacturer is required</i></b>			

**NOTE:** Some fertilizer coulters and row unit combinations result in the fertilizer opener offset from 4"-6" of the center line of the true V-opener.

\*Blade Choices refer to the price book.