

JD 1770 FRONT FOLD PLANTER (12 Row to 24 Row)
JD 7200 FLEX FOLD PLANTER (8 Row Wide to 24 Row Narrow)
JD 7200 RIGID FOLD PLANTER (12 Row Narrow)

Model No.'s to Order for each planter configuration		Quantity to order for each planter			
		8 R W	12 R N	16 R N	24 R N
LIQUID FERT. COULTERS ONLY	2995-014 and 2995-015 T.O.W. opener (no bar kit required)				
	2995-008-R (7" x 7") ^	4	6		
	2995-009-R (3" x 7") ^	4	6		
	2995-005-L and 2995-005-R ^			8 and 8	12 and 12
	2975-128 (front bar kit)			1	
	2995-128 (front bar mtg kit 7200 FF 24R)				1
DRY FERT. COULTERS ONLY	2995-028-R (7" x 7") ^	4	6	N.A.	N.A.
	2995-030-R (2.5 " sq) ^	4	6	N.A.	N.A.
	2990-167 (front fold kit 12 row) Required		1	N.A.	N.A.
	2990-177 (front fold kit 8 row) Required	1		N.A.	N.A.
Unit Mounted Liquid Fertilizer Coupler	2959-003 (2" offset fert. injection)	8	12	16	24
	2967-180 (Residue Manager for 2959-003)				
	or 2961-012 Cut-n-Feed				
	or 2962-001 and 2962-002 RUMDDFO				
	or 2963-001 L & R Challenger				
2960 UNIT MOUNTED CONSERVATION COULTERS ONLY	2960-032 Unit coulters				
	or 2960-034 Coulters w/ U.N.T. bracket				
	or 2960-015 (with spring kit)**	8	12	16	24
	or 2960-127 (coulters only)** Choice of blade				
	2960-126 (spring kit only)				
CLEAN UP CREW ONLY	2965-015 (12" solid blade)				
	or 2965-020 (13" Notched blade)				
	or 2965-022 Screw Adjust Trashmaster				
	or 2967-009 Screw Adjust Short UNT for long arms				
	or 2967-013 Short Narrow U.N.T.				
	or 2967-015 (13" steel wheel)				
	or 2967-028 Universal unit mounted residue manager	8	12	16	24
	or 2967-029 Short U.N.T.				
	or 2967-048 Narrow row unit mounted Residue Manager				
	or 2967-049 Screw Adjust Short UNT				
	or 2967-052 Screw Adjust				
	or 2967-054 Narrow row Screw Adjust				
	or 2967-056 Narrow row Screw Adjust (Long arm)				
	or 2967-057 Screw Adjust (Long arm)				
or 2967-081 (R.M. attachment for JD tool hanger)					
or 2967-092 L & R Notched disc, for JD tool hanger					
or 2967-093 L & R Notched disc screw adjust					
or 2967-094 L & R Notched disc, universal mount					
Combo Attachment	2961-010 Cut-n-Move				
	or 2967-007 U.N.T. Residue Manager kit				
	or 2967-035 Titan Universal				
	or 2967-042 Titan Residue Manager for JD Coulters	8	12	16	24
	or 2967-043 Titan Screw adjust residue manager for JD Coulters				
	or 2967-051 For use with JD Coulters				
	2967-115 (for use with 2960-015 coulters)				
	or 2967-070 (Quick adjust) Optional				
FRAME MOUNTED COULTERS ONLY	2999-109 (basic coulters ass'y 3x7)** Choice of blade	4	6	N.A.	N.A.
	2999-108 (basic coulters ass'y 7x7)** Choice of blade	4	6	N.A.	N.A.

** See the price book for blade choices.

^ Fertilizer placements available are : L & R = left & right standard rear knife, LS & RS = left & right side profile knife

LIHD & RIHD = left & right hand injection (tips not included). See glossary for illustrations.

Continued on page 30

JD 1770 FRONT FOLD PLANTER (12 Row to 24 Row)
JD 7200 FLEX FOLD PLANTER (8 Row Wide - 24 Row Narrow)
JD 7200 RIGID FOLD PLANTER (12 Row Narrow)

Combination of Coulters		Quantity to order for each planter				
		8 R W	12 R N	16 R N	24 R N	
<i>Model No.'s to Order for each planter configuration</i>						
DOUBLE COULTERS						
2 LIQUID FERT. COULTERS ONLY	2995-035-L (3" offset) ^		8	12	N.A.	N.A.
	2995-035-R (3" offset) ^		8	12	N.A.	N.A.
	2975-172 (mounting kit, 12 row only)***	Required		1	N.A.	N.A.
	2990-167 (front fold kit 12 row only)	Required		1	N.A.	N.A.
	2990-177 (front fold kit 8 row only)	Required	1		N.A.	N.A.
	2990-176 (reinforcing bracket)	Required	2	4	N.A.	N.A.
1 DRY / 1 LIQUID FERT. COULTERS ONLY	2995-025-L (Dry Fert., 3" offset) ^		8	12	N.A.	N.A.
	2995-035-L (Liquid Fert., 3" offset) ^		8	12	N.A.	N.A.
	2975-172 (mounting kit)***	Required		1	N.A.	N.A.
	2990-167 (front fold kit 12 row only)	Required		1	N.A.	N.A.
	2990-177 (front fold kit 8 row only)	Required	1		N.A.	N.A.
	2990-176 (reinforcing bracket)	Required	2	4	N.A.	N.A.
1 NO-TILL / 1 FERT. COULTER ONLY	2999-135 (basic coulters 2.5" sq, 3" offset)**	Choice of blade	8	12	N.A.	N.A.
	2995-025-L (Dry Fert., 3" offset) ^	Choose	8 or	12 or	N.A.	N.A.
	or 2995-035-L (Liquid Fert., 3" offset) ^	either model	8	12	N.A.	N.A.
	2975-172 (mounting kit)***	Required		1	N.A.	N.A.
	2990-167 (front fold kit 12 row only)	Required		1	N.A.	N.A.
	2990-177 (front fold kit 8 row only)	Required	1		N.A.	N.A.
	2990-176 (reinforcing bracket)	Required	2	4	N.A.	N.A.
2 NO-TILL COULTER ONLY	2999-135 (basic coulters 2.5" sq, 3" offset)**	Choice of blade	16	24	N.A.	N.A.
	2975-172 (mounting kit)***	Required		1	N.A.	N.A.
	2990-167 (front fold kit 12 row only)	Required		1	N.A.	N.A.
	2990-177 (front fold kit 8 row only)	Required	1		N.A.	N.A.
	2990-176 (reinforcing bracket)	Required	2	4	N.A.	N.A.

** See the price book for blade choices.

*** This kit may be replaced by welding a short piece of a 2 1/2" sq. bar under the tongue along with 2975-175 (8 row) or 2975-176 (12 row) will be required - however Yetter is not responsible for any damage caused by doing so.

**** The Clean Up Crew and Unit Mounted Coulters cannot be used together, with the exception of the 2967-115, if using the 2967-115 combination in conjunction with Frame Mounted Fertilizer Coulters, Fertilizer Coulters can only be mounted 4" or farther from the row.

^ Fertilizer placements available are : L & R = left & right standard rear knife, LS & RS = left & right side profile knife
 LIHD & RIHD = left & right hand injection (tips not included). See glossary for illustrations.

Continued on pg 31

JD 1770 FRONT FOLD PLANTER (12 Row to 24 Row)
JD 7200 FLEX FOLD PLANTER (8 Row Wide - 24 Row Narrow)
JD 7200 RIGID FOLD PLANTER (12 Row Narrow)

Combination of Coulters		Quantity to order for each planter			
		8 R W	12 R N	16 R N	24 R N
<i>Model No.'s to Order for each planter configuration</i>					
1 LIQUID FERTILIZER AND COMBO UNIT ONLY	2995-008-R (7" x 7") ^	4	6		
	2995-009-R (3" x 7") ^	4	6		
	2995-005-L and 2995-005-R ^			8 and 8	12 and 12
	2975-128 (front bar kit)			1	
	2995-128 (front bar mounting kit 7200 FF 24 R				1
	2975-189 (set back) Required	8	12	16	24
	2960-015 (coulters with spring kit)** See below				
	or 2960-034 Coulters w/ U.N.T. bracket	8	12	16	24
	or 2960-127 (coulters only)**				
	2967-007 U.N.T. Residue Manager kit				
or 2967-035 Titan Universal					
or 2967-042 Titan Residue Manager for JD Coulters	8	12	16	24	
or 2967-043 Titan Screw adjust residue manager for JD Coulters					
or 2967-051 For use with JD Coulters					
or 2967-115 (for use with 2960-015)					
2960-034 Coulters w/ U.N.T. bracket See below					
or 2960-015 (coulters with spring)**					
or 2960-127 (coulters only)**	8	12	16	24	
1 JD LIQUID FERTILIZER AND COMBO UNIT ONLY	2967-007 U.N.T. Residue Manager kit				
	or 2967-035 Titan Universal				
	or 2967-042 Titan Residue Manager for JD Coulters	8	12	16	24
	or 2967-043 Titan Screw adjust residue manager for JD Coulters				
	or 2967-051 For use with JD Coulters				
	or 2967-115 (for use with 2960-015)****				
2967-070 (Quick adjust)					
2975-189 (set back) Required	8	12	16	24	

** See the price book for blade choices.

*** This kit may be replaced by welding a short piece of a 2 1/2" sq. bar under the tongue along with 2975-175 (8 row) or 2975-176 (12 row) will be required - however Yetter is not responsible for any damage caused by doing so.

**** The Clean Up Crew and Unit Mounted Coulters cannot be used together, with the exception of the 2967-115, if using the 2967-115 combination in conjunction with Frame Mounted Fertilizer Coulters, Fertilizer Coulters can only be mounted 4" or farther from the row.

^ Fertilizer placements available are : L & R = left & right standard rear knife, LS & RS = left & right side profile knife

LIHD & RIHD = left & right hand injection (tips not included). See glossary for illustrations.