

JD 1790 & 1795 DOUBLE CROP SOYBEAN SEEDING SYSTEM

Recommendations made here are NOT to be used in No-till cornstalk residue.

Use of Residue Managers in 15" Rows for planting soybeans directly into harvested wheat stubble.

Coulter/Residue Manager Combination - 1790 planter must be equipped with ordering code 5415. Included in code 5415 are long parallel arms, long drive cables, vacuum hoses, seed delivery hoses and down force spacers.

Model No's to Order for each planter configuration		Quantity to order for each planter	
		23/24R (15")	31/32R (15")
2960 UNIT MOUNTED CONSERVATION COULTERS ONLY	2960-034 Coulter w/ U.N.T. bracket ** or 2960-127 (coulter only)**	23/24	31/32
CLEAN UP CREW ONLY	2940-001A Pneumatic assembly or 2940-002 Pneumatic assembly narrow row or 2967-013A Short Narrow U.N.T. or 2967-028 Universal unit mounted residue manager or 2967-029A Short U.N.T. or 2967-048 Narrow row unit mounted Residue Manager or 2967-052 Screw Adjust^ or 2967-054 Narrow Row Screw Adjust^ or 2967-056 Narrow Row Screw Adjust (Long arm)^ or 2967-057 Screw Adjust (Long arm)^ or 2967-081 (R.M. attachment for JD tool hanger)	23/24	31/32
Residue Manager Combinations	2967-007 U.N.T. Residue Manager Kit or 2967-042A Titan Residue Manager for JD Coulter or 2967-115 (for use with 2960-127 coulter) or 2967-070 (Quick adjust) Optional	23/24	31/32

**Blade Choices refer to price book.

^ Quantity to order varies depending on which parallel arm "ordering code" the planter is equipped