

# KINZE ECONO FOLD II PLANTER

Equipped with no options

8 Row Narrow, 8 Row Wide, and 12 Row Narrow

<i>Model No.'s to Order for each planter configuration</i>		<i>Quantity to order for each planter</i>		
		<b>8 R N</b>	<b>8 R W</b>	<b>12 R N</b>
<b>LIQUID FERT. COULTER FRAME MOUNTED</b>	<b>NOT AVAILABLE</b>			
<b>Unit Mounted</b>	2959-003 (2" offset fert. injection)	<b>8</b>	<b>8</b>	<b>12</b>
<b>Liquid Fertilizer Coulters</b>	w/ 2967-180A (Residue manager for 2959-003) Optional			
	2975-188 (Set back bracket) Required	<b>2</b>	<b>2</b>	<b>2</b>
	or 2962-003A and 2962-004A RUMDDFO			
	w/ 2962-005 (Residue Manager for 2962-003/-004) Optional			
	or 2968-021A-R-LB/-L-LB Row Unit mount			
	& 2968-132 10" wheel or 2968-133 11" wheel assembly			
<b>2960 UNIT MOUNTED CONSERVATION COULTERS ONLY</b>	2960-033 Coulters w/ U.N.T. bracket (Kinze)** or 2960-127 (unit coulters only)**	<b>8</b>	<b>8</b>	<b>12</b>
<b>CLEAN UP CREW ONLY</b>	2940-001 Pneumatic assembly or 2967-013A Short / Narrow UNT or 2967-028 Universal unit mounted residue manager or 2967-029A Short UNT or 2967-048 Narrow row unit mounted Residue Manager or 2967-052 Screw Adjust ( 1993 - current) or 2967-054 Narrow row Screw Adjust ( 1993 - current) or 2967-056 Narrow row Screw Adjust (pre- 1993) or 2967-057 Screw Adjust (pre- 1993)	<b>8</b>	<b>8</b>	<b>12</b>
<b>Combination Attachments</b>	2967-006 Floating Residue Manager fits Kinze Unit Mount Coulters or 2967-007 U.N.T. (use with 2960-033 coulters) or 2967-035 Titan or 2967-115 (for use with 2960-127 coulters) 2967-070 (Quick adjust) Optional	<b>8</b>	<b>8</b>	<b>12</b>

\*\* See the price book for blade choices.

NOTE - DUE TO MANUFACTURING CHANGES IN PLANTER SOME ATTACHMENTS MAY NOT BE USED OR MODIFIED.