

# KINZE TWINLINE II/2300 PULL TYPE PLANTER

Equipped with Kinze Fertilizer Frame

8 Row Narrow / Wide, 12 Row Narrow / Wide, and 16 Row Narrow / Wide

Model No.'s to Order for each planter configuration		Quantity to order for each planter		
		8 R N/W	12 R N/ 12 R W	16 R N
<b>LIQUID FERT. COULTER</b>	2995-017	<b>8</b>	<b>12</b>	<b>16</b>
<b>FRAME MOUNTED</b>	or 2995-065-L/R^ <b>order 2990-154 &amp; 2990-310 and choice of blade</b>	<b>4 and 4</b>	<b>6 and 6</b>	<b>8 and 8</b>
<b>DRY FERT. COULTERS ONLY</b>	<b>NOT AVAILABLE</b>			
<b>Unit Mounted</b>	2959-003 (2" offset fert. injection)	<b>8</b>	<b>12</b>	<b>16</b>
<b>Liquid Fertilizer Coulters</b>	w/ 2967-180A (Residue manager for 2959- Optional or 2962-003A and 2962-004A RUMDDFO w/ 2962-005 (Residue Manager for 2962-0l Optional or 2968-021A-R-LB/-L-LB Row Unit mount & 2968-132 10" wheel or 2968-133 11" wheel assembly	<b>NA</b>	<b>NA</b>	<b>NA</b>
<b>2960 UNIT MOUNTED CONSERVATION COULTERS ONLY</b>	2960-033 Coulters w/ U.N.T. bracket (Kinze)** or 2960-127 (unit coulters only)**	<b>8</b>	<b>12</b>	<b>16</b>
<b>CLEAN UP CREW ONLY</b>	2940-001 Pneumatic assembly or 2967-013A Short / Narrow UNT or 2967-028 Universal unit mounted residue manager or 2967-029A Short UNT or 2967-048 Narrow row unit mounted Residue Manager or 2967-052 Screw Adjust (1993 - current) or 2967-054 Narrow row Screw Adjust ( 1993 - current) or 2967-056 Narrow row Screw Adjust (pre- 1993) or 2967-057 Screw Adjust (pre- 1993)	<b>8</b>	<b>12</b>	<b>16</b>
<b>Combination Attachments</b>	2967-006 Floating Residue Manager fits Kinze Unit Mount Coulters or 2967-007 U.N.T. (use with 2960-033 coulters) or 2967-035 Titan or 2967-115 (for use with 2960-127 coulters)* 2967-070 (Quick adjust) Optional 2975-188 (set back brackets)*** Required	<b>12</b>	<b>12</b>	<b>16</b>
		<b>4</b>	<b>4</b>	<b>4</b>
	2995-065-L/R^ <b>order 2990-154 &amp; 2990-310 and choice of blade</b>	<b>4 and 4</b>	<b>6 and 6</b>	<b>8 and 8</b>
<b>1 LIQUID FERTILIZER AND</b>	2960-033 Coulters w/ U.N.T. bracket (Kinze) or 2960-127 (coulters only)** Choice of blade	<b>8</b>	<b>12</b>	<b>16</b>
<b>1 COMBO UNIT</b>	2967-006 Floating Residue Manager fits Kinze Unit Mount Coulters or 2967-007 U.N.T. (use with 2960-033 coulters) or 2967-035 Titan Universal or 2967-115 (for use with 2960-127 coulters) 2975-188 (set back brackets)*** Required	<b>8</b>	<b>12</b>	<b>16</b>
		<b>4</b>	<b>4</b>	<b>4</b>
<b>FRAME MOUNTED COULTERS ONLY</b>	2999-101 (basic coulters ass'y)** <b>Order 2990-154, 2990-310 and choice of blade</b>	<b>8</b>	<b>12</b>	<b>16</b>

\*\* See the price book for blade choices.

\*\*\* Must be used on center 4 rows when using Combination attachments

NOTE - DUE TO MANUFACTURING CHANGES IN PLANTER SOME ATTACHMENTS MAY NOT BE USED OR MODIFIED.

# KINZE TWINLINE II/2300 PULL TYPE PLANTER

Equipped without Kinze Fertilizer Frames

8 Row Narrow / Wide, 12 Row Narrow / Wide, and 16 Row Narrow / Wide

Model No.'s to Order for each planter configuration

		Quantity to order for each planter			
		8 R N/W	12 R N	12 R W	16 R N
<b>LIQUID FERT. COULTER</b>	2995-017 <i>order 2990-154 &amp; 2990-318 and choice of blade</i>	8 or 4 and 4	12 or 6 and 6	12 or 6 and 6	16 or 8 and 8
	2995-065-L/R^ <i>order 2990-154 &amp; 2990-318 and choice of blade</i>				
<b>FRAME MOUNTED</b>	2990-325 (bar)**** Required				2
	2990-148 (front bar mount kit)**** Required	2	1	3	3
<b>DRY FERT. COULTERS ONLY</b>	N/A				
<b>Unit Mounted</b>	2959-003 (2" offset fert. injection)	8	12	12	16
<b>Liquid Fertilizer Coulters</b>	w/ 2967-180A (Residue manager for 2959-003) Optional	NA	NA	NA	NA
	or 2962-003A and 2962-004A RUMDDFO				
	w/ 2962-005 (Residue Manager for 2962-003/-004) Optional				
	or 2968-021A-R-LB/-L-LB Row Unit mount & 2968-132 10" wheel or 2968-133 11" wheel assembly				
<b>2960 UNIT MOUNTED CONSERVATION COULTERS ONLY</b>	2960-033 Coulters w/ U.N.T. bracket (Kinze) or 2960-127 (unit coulters only)**	8	12	12	16
<b>CLEAN UP CREW ONLY</b>	2940-001 Pnematic assembly or 2967-013A Short / Narrow UNT or 2967-028 Universal unit mounted residue manager or 2967-029A Short UNT or 2967-048 Narrow row unit mounted Residue Manager or 2967-052 Screw Adjust (1993 - current) or 2967-054 Narrow row Screw Adjust (1993 - current) or 2967-056 Narrow row Screw Adjust (pre- 1993) or 2967-057 Screw Adjust (pre- 1993)	8	12	12	16
<b>Combination Attachments</b>	2967-006 Floating Residue Manager fits Kinze Unit Mount Coulters or 2967-035 Titan	8	12	12	16
	or 2967-115 (for use with 2960-127 coulters)				
	2967-070 (Quick adjust) Optional				
	2975-188 (set back brackets)**** Required	4	4	4	4

Double coulters continued on next page

\*\* See the price book for blade choices.

\*\*\* Must be used on center 4 rows when using Combination attachments

\*\*\*\* Front bar kit may require some cutting and u-bolts, part # 2570-477.

NOTE - DUE TO MANUFACTURING CHANGES IN PLANTER SOME ATTACHMENTS MAY NOT BE USED OR MODIFIED.

# KINZE TWINLINE II/2300 PULL TYPE PLANTER

Equipped without Kinze Fertilizer Frames

8 Row Narrow / Wide, 12 Row Narrow / Wide, and 16 Row Narrow / Wide

<i>Model No.'s to Order for each planter configuration</i>		<i>Quantity to order for each planter</i>			
		<b>8 R N/W</b>	<b>12 R N</b>	<b>12 R W</b>	<b>16 R N</b>
<b>DOUBLE COULTERS</b>	2995-065-L/R <i>order 2990-154 &amp; 2990-208</i>	<b>8</b>	<b>N.A.</b>	<b>12</b>	<b>16</b>
<b>2 LIQUID FERTILIZER</b>	<i>and choice of blade</i>				
<b>COULTERS</b>	2990-148 (front bar mount kit)**** Required	<b>2</b>	<b>N.A.</b>	<b>3</b>	<b>3</b>
<b>1 NO-TILL / 1 FERT.</b>	2999-101 (basic coulters)** Order 2990-154, 2990-208 & blade	<b>8</b>	<b>N.A.</b>	<b>12</b>	<b>16</b>
<b>COULTERS</b>	2995-035-L^	<b>8</b>	<b>N.A.</b>	<b>12</b>	<b>16</b>
	<i>order 2990-154 &amp; 2990-208 and choice of blade</i>				
	2990-148 (front bar mount kit)**** Required	<b>2</b>	<b>N.A.</b>	<b>3</b>	<b>3</b>
<b>2 NO-TILL</b>	2999-101 (basic coulters)** Order 2990-154, 2990-208 & blade	<b>16</b>	<b>N.A.</b>	<b>24</b>	<b>32</b>
<b>COULTERS</b>	2990-148 (front bar mount kit)**** Required	<b>2</b>	<b>N.A.</b>	<b>3</b>	<b>3</b>
<b>1 LIQUID FERTILIZER</b>	2995-065-L/R^ <i>order 2990-154 &amp; 2990-318</i>	<b>4 and 4</b>	<b>N.A.</b>	<b>6 and 6</b>	<b>8 and 8</b>
	<i>and choice of blade</i>		<b>N.A.</b>		
<b>AND</b>	2990-325 (front bar)****		<b>N.A.</b>		<b>2</b>
	2990-148 (front bar kit)****	<b>2</b>	<b>N.A.</b>	<b>3</b>	<b>3</b>
<b>1 COMBO UNIT</b>	2960-033 Coulters w/ U.N.T. bracket (Kinze)		<b>N.A.</b>		
	or 2960-127 (coulters only)**	<b>8</b>	<b>N.A.</b>	<b>12</b>	<b>16</b>
	2967-006 Floating Residue Manager fits Kinze Unit Mount Coulters				
	or 2967-007 U.N.T. (use with 2960-033 coulters)				
	or 2967-035 Titan Universal	<b>8</b>	<b>N.A.</b>	<b>12</b>	<b>16</b>
	or 2967-115 (for use with 2960-127 coulters)				
	2975-188 (set back brackets)*** Required	<b>4</b>	<b>N.A.</b>	<b>4</b>	<b>4</b>

\*\* See the price book for blade choices.

\*\*\* Must be used on center 4 rows when using Combination attachments.

\*\*\*\* Front bar kit may require some cutting and u-bolts, part # 2570-477.

NOTE - DUE TO MANUFACTURING CHANGES IN PLANTER SOME ATTACHMENTS MAY NOT BE USED OR MODIFIED.