

CASE/IH 800-900/950-955 PLANTER

Equipped with 2" x 6" fertilizer frame and tanks plus Endwise Transport
8 Row Narrow, 8 Row Wide, and 12 Row Narrow

<i>Model No.'s to Order for each planter configuration</i>			<i>Quantity to order for each planter</i>		
			8 R N	8 R W	12 R N
UNIT MOUNT FERT COULTERS	2968-030 Fertilizer injection kit		8	8	12
LIQUID FERT. COULTER FRAME MOUNTED	2995-017 <i>order 2990-155 & 3010-303 and choice of blade</i> or 2995-065-L/R^ <i>order 2990-155 3010-303 and choice of blade</i>		8 or 4 and 4	8 or 4 and 4	12 or 6 and 6
DRY FERT. COULTER FRAME MOUNTED	NOT AVAILABLE				
2960 UNIT MOUNTED CONSERVATION COULTERS ONLY	2960-020-MW (unit coulters only with 25 wave blade) Choice of one style		8	8	12
CLEAN UP CREW ONLY	2940-003A Pneumatic assembly or 2967-014A Short / Narrow UNT or 2967-036 Narrow row residue manager or 2967-053 Screw Adjust or 2967-097A Short titan residue manager or 2967-106 (13" steel wheel)***&				
COMBO ATTACHMENT	w/ 2967-008 Titan (for use with 2960-020 coulters) Optional		8	8	12
FRAME MOUNTED COULTERS ONLY	2999-101 (basic coulters ass'y)** Choice of blade Order 2990-155, 3010-303 & blade		8	8	12
DOUBLE COULTERS 2 LIQUID FERT. COULTERS	2995-065-L/R (fits 2" x 6" bar) ^ <i>order 2990-155 & 3010-303 (Half) and choice of blade</i> 3011-302 (5" offset Shank) (Half) 2920-305 (swivel collar)**** Required		8	8	12
1 NO-TILL / 1 FERT. COULTERS	2999-101 (basic coulters ass'y)** Choice of blade Order 2990-155, 3010-303 & blade		8	8	12
2 NO-TILL COULTERS	2999-101 (basic coulters ass'y)** Order 2990-155, 3010-303/3011-302 & blade 2920-305 (swivel collar)**** Required		16	16	24
1 LIQUID FERT. AND 1 COMBO UNIT	2995-065-L/R^ <i>order 2990-155 & 3010-303 and choice of blade</i> 2960-020-MW (unit coulters only with 25 wave blade) w/ 2967-008 Titan (for use with 2960-020 coulters) Optional		4 and 4 8 8	4 and 4 8 8	6 and 6 12 12

** See the price book for choice of blades.

**** The swivel collar is required for the two coulters which must be rotated to clear the transport wheel.

& First year production of 800 planter requires Case/IH unit mount plate or modification of the planter unit.

NOTE - ON PLANTERS EQUIPPED WITH DOUBLE COULTERS - BEFORE TRANSPORTING, 2 COULTERS MUST BE ROTATED TO CLEAR TRANSPORT WHEEL.

NOTE - IF FERTILIZER FRAME OR OPTIONAL FRAME MOUNTED COULTERS ARE USED IN CONJUNCTION AND THEY ARE MOUNTED IN THE CENTER OF THE ROW, FERTILIZER COULTERS CAN ONLY BE MOUNTED 4" OR FARTHER FROM THE ROW.

CASE/IH 800-900/950-955 PLANTER

Equipped with Endwise Transport and no other options

8 Row Wide and 12 Row Narrow

<i>Model No.'s to Order for each planter configuration</i>		<i>Quantity to order for each planter</i>	
		8 R N	12 R N
UNIT MOUNT FERT COULTER	2968-030 Fertilizer injection kit	8	12
LIQUID FERT. COULTER FRAME MOUNTED	2995-017 <i>order 2990-154 & 3010-303 and choice of blade</i> or 2995-065-L/R^ <i>order 2990-154 & 3010-303 and choice of blade</i> 2970-179 (front bar mount kit) Required	8 or 4 and 4	12 or 6 and 6
DRY FERT. COULTER FRAME MOUNTED	NOT AVAILABLE		
2960 UNIT MOUNTED CONSERVATION COULTERS ONLY	2960-020-MW (unit coulters only with 25 wave blade)	8	12
CLEAN UP CREW ONLY	2940-003A Pneumatic assembly or 2967-014A Short / Narrow UNT or 2967-036 Narrow row residue manager or 2967-053 Screw Adjust residue manager or 2967-097A Short titan residue manager or 2967-106 (13" steel wheel)	8	12
COMBO ATTACHMENT	2967-008 Titan (for use with 2960-020 coulters)	8	12
Frame Mounted	2999-101 (basic coulters ass'y)** Order 2990-154, 3010-303 & blade	8	12
Coulters Only	2970-179 (front bar mount kit)	2	2

** See the price book for blade choices.

**** The swivel collar is required for the two coulters which must be rotated to clear the transport wheel.

(see the note below and the illustration on page 10)

& First year production of 800 planter requires Case/IH unit mount plate or modification of planter unit.

NOTE - IF FERTILIZER FRAME OR OPTIONAL FRAME MOUNTED COULTERS ARE USED IN CONJUNCTION AND THEY ARE MOUNTED IN THE CENTER OF THE ROW, FERTILIZER COULTERS CAN ONLY BE MOUNTED 4" OR FARTHER FROM THE ROW.

NOTE - ON PLANTERS EQUIPPED WITH DOUBLE COULTERS - BEFORE TRANSPORTING, 2 COULTERS MUST BE ROTATED TO CLEAR TRANSPORT WHEEL.

CASE/IH 800-900/950-955 PLANTER

Equipped with Endwise Transport and no other options

8 Row Wide and 12 Row Narrow

<i>Model No.'s to Order for each planter configuration</i>		<i>Quantity to order for each planter</i>	
		8 R W	12 R N
DOUBLE COULTERS	2995-065-L^ order 2990-154 & 3010-303 and choice of blade	8	12
2 LIQUID FERT. COULTERS	2995-065-R^ order 2990-154 & 3011-302 and choice of blade	8	12
	2970-179 (front bar mount kit) Required	2	2
	2920-305 (swivel collar)**** Required	2	3
1 NO-TILL / 1 FERT. COULTERS	2999-101 (basic coultter ass'y)** Order 2990-154, 3010-303 & blade	8	12
	2995-065-L^ order 2990-154 & 3011-302 and choice of blade	8	12
	2970-179 (front bar mount kit) Required	2	2
	2920-305 (swivel collar)**** Required	2	3
2 NO-TILL COULTERS	2999-101 (basic coultter ass'y)** Order 2990-154, 3010-303/3011-302 & blade	16	24
	2970-179 (front bar mount kit) Required	2	2
	2920-305 (swivel collar)**** Required	2	3
1 LIQUID FERT. AND 1 COMBO UNIT	2995-065-L/R^ order 2990-154 & 3011-302 and choice of blade	4 and 4	6 and 6
	2970-179 (front bar mount kit) Required	2	2
	2920-305 (swivel collar)**** Required	2	3
	2960-020-MW (unit coultter only with 25 wave blade)	8	12
	w/ 2967-008 Titan (for use with 2960-020 coultter) Optional	8	12

** See the price book for blade choices.

**** The swivel collar is required for the two coultters which must be rotated to clear the transport wheel.

(see the note below and the illustration on page 10)

& First year production of 800 planter requires Case/IH unit mount plate or modification of planter unit.

NOTE - IF FERTILIZER FRAME OR OPTIONAL FRAME MOUNTED COULTERS ARE USED IN CONJUNCTION AND THEY ARE MOUNTED IN THE CENTER OF THE ROW, FERTILIZER COULTERS CAN ONLY BE MOUNTED 4" OR FARTHER FROM THE ROW.

NOTE - ON PLANTERS EQUIPPED WITH DOUBLE COULTERS - BEFORE TRANSPORTING, 2 COULTERS MUST BE ROTATED TO CLEAR TRANSPORT WHEEL.