

# JD / Bauer Planter

Model No.'s to Order for each planter configuration

		24 R	24 R	32 R	36 R	36 R	32 R	36 R	48 R	48 R	48 R
		22"	30"	22"	20"	22"	30"	30"	20"	22"	30"
		48	60	58	60	66	80	90	80	88	120
<b>Liquid Fert. Coulter Only</b>	<b>NOT AVAILABLE</b>										
<b>Unit Mounted Liquid Fertilizer</b>	2959-003 (2" offset fert. injection) 2967-180B (Residue Manager for 2959-003) Optional or 2962-003A and 2962-004A RUMDDFO w/ 2962-005B Residue Manager for 2962-003A/-004 Optional or 2968-020B-R-LB/-L-LB Row Unit mount fits 1700-7200-7300 & 2968-132 10" wheel assembly	24 N/A N/A 24 24	24 N/A N/A 24 24	32 N/A N/A 32 32	36 N/A N/A 36 36	36 N/A N/A 36 36	32 N/A N/A 32 32	36 N/A N/A 36 36	48 N/A N/A 48 48	48 N/A N/A 48 48	48 N/A N/A 48 48
<b>2960 Unit Mount Conservation Coulters Only</b>	2960-034 Coulter w/ UNT bracket or 2960-127 (coulter only)*	24	24	32	36	36	32	36	48	48	48
<b>CLEAN UP CREW ONLY</b>	2940-001B Pneumatic assembly or 2967-029B Short U.N.T. or 2967-052A Screw Adjust or 2967-057A Screw Adjust (Long arm) or 2967-081A (R.M. attachment for JD tool hanger)	N/A	24	N/A	N/A	N/A	32	36	N/A	N/A	48
	2940-002B Pneumatic assembly narrow row or 2967-013B Short Narrow U.N.T. or 2967-048A Narrow row unit mounted Residue Manager or 2967-054A Narrow row Screw Adjust or 2967-056A Narrow row Screw Adjust (Long arm)	24	24	32	36	36	32	36	48	48	48
<b>Combo Attachment</b>	2967-007A U.N.T. Residue Manager kit or 2967-042B Titan Residue Manager for JD Coulter or 2967-115A (for use with 2960-015 coulter) Optional 2967-070 (Quick adjust)	N/A	24	N/A	N/A	N/A	32	36	N/A	N/A	48
<b>Long parallel arms required on rows near lift wheels</b>											

\*Blade Choices refer to price book.