

JD 1780 FRONT FOLD PLANTER

Equipped with no options

Model No's to Order for each planter configuration

			Quantity to order for each planter				
			12 Row 30" or 23 Row 15"	16 Row 30" or 31 Row 15"	16 Row 22"	24 Row 20"	
Unit Mounted	2959-003 (2" offset fert. injection)		12/23	16/31	16	24	
Liquid Fertilizer Coulter	w/	2967-180A (Residue Manager for 2959-003)	Optional	N/A	N/A	N/A	N/A
	or	2962-003A and 2962-004A RUMDDFO					
	w/	2962-005 (Residue Manager for 2962-003/-004)	Optional	6 & 6	8 & 8	8 & 8	12 & 12
	or	2968-020A-R-LB/-L-LB Row Unit mount fits 1700, 7200 & 7300 & 2968-132 10" wheel or 2968-133 11" wheel assembly					
2960 UNIT MOUNTED CONSERVATION COULTERS ONLY		2960-034 Coulter w/ U.N.T. bracket**					
	or	2960-127 (coulter only)**	12 or 23	16 or 31	16	24	
CLEAN UP CREW ONLY		2940-001A Pneumatic assembly					
	or	2967-028 Universal unit mounted residue manager	12	16	N/A	N/A	
	or	2967-029A Short U.N.T.					
	or	2967-052 Screw Adjust (Short arm)					
or	2967-057 Screw Adjust (Long arm)						
	or	2967-081 (R.M. attachment for JD tool hanger)**					
Combination Attachments		2940-002A Pneumatic assembly narrow row					
	or	2967-013A Short Narrow U.N.T.	23	31	16	24	
	or	2967-048 Narrow row unit mounted residue manager					
	or	2967-054 Narrow row Screw Adjust (short arm)					
	or	2967-056 Narrow row Screw Adjust (long arm)					
	or	2967-007 U.N.T. Residue manager kit					
or	2967-035 Titan Universal	12^					16^
or	2967-042A Titan residue manager for JD Coulter						
or	2967-115 (for use with 2960-127 coulter)**						
or	2967-070 (Quick adjust kit)						
		Optional					

**Blade Choices refer to price book.

** 30" minimum row spacing only

*** 15"/20",22" row spacing

^ Two row units (30" spacing) near lift wheels need 21" long parallel arms