

# JD 1780, 1785 & 7240 DRAWN RIGID PLANTER

Equipped with no options

Model No.'s to Order for each planter configuration

		Quantity to order for each planter		
		4/9 Row 36"/18",38"/19"	6/11 Row 30"/15" 36"/18",38"/19"	8/15 Row 30"/15"
<b>LIQUID FERT. COULTER FRAME MOUNTED</b>	2995-017 <i>order 2990-154 &amp; 2990-318 and choice of blade</i>	<b>4 or 9</b>	<b>6 or 11</b>	<b>8 or 15</b>
	or 2995-065-L/R ^ <i>order 2990-154 &amp; 2990-318 and choice of blade</i>	<b>2 &amp; 2 / 4 &amp; 5</b>	<b>3 &amp; 3 / 6 &amp; 5</b>	<b>4 &amp; 4 / 8 &amp; 7</b>
	67" Front Bar Mount Kit\$	<b>1</b>	<b>1(30")</b>	
	100" Front Bar Mount Kit\$		<b>1(36",38")</b>	<b>1</b>
<b>DRY FERT. COULTER FRAME MOUNTED</b>	<b>NOT AVAILABLE</b>			
<b>Unit Mounted</b>	2959-003 (2" offset fert. injection)	<b>4 or 9</b>	<b>6 or 11</b>	<b>8 or 15</b>
<b>Liquid Fertilizer Coulters</b>	w/ 2967-180A (Residue Manager for 2959-003)** Optional	<b>4</b>	<b>6</b>	<b>8</b>
	or 2962-003A and 2962-004A RUMDDFO			
	w/ 2962-005 (Residue Manager for 2962-003/-004) Optional			
	or 2968-020A-R-LB/-L-LB Row Unit mount fits 1700, 7200 & 7300 & 2968-132 10" wheel or 2968-133 11" wheel assembly			
<b>2960 UNIT MOUNTED CONSERVATION COULTERS ONLY</b>	2960-034 Coulters w/ U.N.T. bracket ** or 2960-127 (coulters only)**	<b>4 or 9</b>	<b>6 or 11</b>	<b>8 or 15</b>
<b>CLEAN UP CREW ONLY</b>	2940-001A Pneumatic assembly or 2967-028 Universal unit mounted residue manager or 2967-029A Short U.N.T.	<b>4</b>	<b>6</b>	<b>8</b>
	or 2967-052 Screw Adjust or 2967-057 Screw Adjust (Long arm)			
	2967-081 (R.M. attachment for JD tool hanger)****			
	2940-002A Pneumatic assembly narrow row or 2967-013A Short Narrow U.N.T.	<b>9</b>	<b>11</b>	<b>15</b>
	or 2967-048 Narrow row unit mounted Residue Manager or 2967-054 Narrow row Screw Adjust	<b>4</b>	<b>6</b>	<b>8</b>
<b>COMBO ATTACHMENT</b>	or 2967-056 Narrow row Screw Adjust (Long arm)	<b>5</b>	<b>5</b>	<b>7</b>
	2967-007 U.N.T. Residue Manager kit or 2967-035 Titan (Universal)			
	or 2967-042A Titan Residue Manager for JD Coulters or 2967-115 (for use with 2960-127 coulters only)**	<b>4</b>	<b>6</b>	<b>8</b>
	2967-070 (Quick adjust kit) Optional			

\*\*Blade Choices refer to price book.

\*\*\*\* 30" Row Spacing is a minimum

\*\*\*15", 18" and 19" Row Spacing

\$ Call Yetter for Price and Details

# JD 1780, 1785 & 7240 DRAWN RIGID PLANTER

Equipped with no options

Model No.'s to Order for each planter configuration

		Quantity to order for each planter			
		4/9 Row 36"/18",38"/19"	6/11 Row 30"/15" 36"/18",38"/19"	8/15 Row 30"/15"	
<b>DOUBLE COULTERS****</b>					
<b>2 LIQUID FERTILIZER</b>	2995-065-L/R^ <i>order 2990-154 &amp; 2990-208 and choice of blade</i>		4 & 4	6 & 6	8 & 8
<b>COULTER</b>					
<b>FRAME MOUNTED</b>	67" Front Bar Mount Kit\$	Required	1	1(30")	
	100" Front Bar Mount Kit\$	Required		1(36",38")	1
<b>1 NO-TILL / 1 FERT.</b>	2999-101 (basic coultter ass'y)**		Choice of blade		
<b>COULTER</b>	Order 2990-154, 2990-208 & blade		4	6	8
	2995-065-L^ <i>order 2990-154 &amp; 2990-208 and choice of blade</i>		4	6	8
<b>ONLY</b>	67" Front Bar Mount Kit\$	Required	1	1(30")	
	100" Front Bar Mount Kit\$	Required		1(36",38")	1
	2960-034 Coultter w/ U.N.T. bracket**		4 or 9	6 or 11	8 or 15
	or 2960-127 (coultter only)**				
<b>1 COMBO / 1 FERT.</b>	2967-007 U.N.T. Residue Manager kit				
<b>COULTER</b>	or 2967-035 Titan Universal		4	6	8
<b>ONLY</b>	or 2967-042A Titan Residue Manager for JD Coultter				
	or 2967-115 (for use with 2960-127 coultter only)				
	2995-065-L/R^ <i>order 2990-154 &amp; 2990-318 and choice of blade</i>		2 & 2	3 & 3	4 & 4
	67" Front Bar Mount Kit\$	Required	1	1(30")	
	100" Front Bar Mount Kit\$	Required		1(36",38")	1

\*\*Blade Choices refer to price book.

\*\*\*\* 30" Row Spacing is a minimum

\*\*\*\*15", 18" and 19" Row Spacing

\$ Call Yetter for Price and Details