

JD 1770 & 1775 FRONT FOLD PLANTER (12 Row to 24 Row)
JD 7200 FLEX FOLD PLANTER (8 Row Wide to 24 Row Narrow)
JD 7200 RIGID FOLD PLANTER (12 Row Narrow)

| Model No.'s to Order for each planter configuration | | Quantity to order for each planter | | | |
|---|---|------------------------------------|--------|---------|--------|
| | | 8 R W | 12 R N | 16 R N | 24 R N |
| LIQUID FERT. COULTER FRAME MOUNTED | 2995-065-L/R (7" x 7") ^ <i>order 2990-158 & 3010-303 and choice of blade.</i> | 4 | 6 | | |
| | 2995-065-L/R (3" x 7") ^ <i>order 2990-161 & 3010-303 and choice of blade</i> | 4 | 6 | | |
| | 2995-065-L/R <i>order 2990-154 & 2990-310 and choice of blade</i> | | | 8 and 8 | N.A. |
| | | | | | |
| DRY FERT. COULTER FRAME MOUNTED | 2995-075-L/R (7" x 7") ^ <i>order 2990-158 & 3010-303 and choice of blade</i> | 4 | 6 | N.A. | N.A. |
| | 2995-075-L/R (2.5" sq) ^ <i>order 2990-154 & 2990-318 and choice of blade.</i> | 4 | 6 | N.A. | N.A. |
| | 2990-167 (front fold kit 12 row) Required | N.A. | 1 | N.A. | N.A. |
| Unit Mounted | 2959-003 (2" offset fert. injection) | | | | |
| Liquid Fertilizer Coulters | w/ 2967-180A (Residue Manager for 2959-003) Optional | | | | |
| | or 2962-003A and 2962-004A RUMDDFO | | | | |
| | w/ 2962-005 (Residue Manager for 2962-003/-004) Optional | | | | |
| | or 2968-020A-R-LB/-L-LB Row Unit mount fits 1700, 7200 & 7300 & 2968-132 10" wheel or 2968-133 11" wheel assembly | 8 | 12 | 16 | 24 |
| 2960 UNIT MOUNTED CONSERVATION COULTERS ONLY | 2960-034 Coulters w/ U.N.T. bracket** | | | | |
| | or 2960-127 (coulters only)** Choice of blade | 8 | 12 | 16 | 24 |
| | 2960-126 (spring kit only) Optional | | | | |
| CLEAN UP CREW ONLY | 2940-001A Pneumatic assembly | | | | |
| | or 2967-013A Short Narrow U.N.T. | | | | |
| | or 2967-028 Universal unit mounted residue manager | 8 | 12 | 16 | 24 |
| | or 2967-029A Short U.N.T. | | | | |
| | or 2967-048 Narrow row unit mounted Residue Manager | | | | |
| | or 2967-052 Screw Adjust | | | | |
| | or 2967-054 Narrow row Screw Adjust | | | | |
| | or 2967-056 Narrow row Screw Adjust (Long arm) | | | | |
| or 2967-057 Screw Adjust (Long arm) | | | | | |
| Combo Attachment | or 2967-081 (R.M. attachment for JD tool hanger) | | | | |
| | 2967-007 U.N.T. Residue Manager kit | | | | |
| | or 2967-035 Titan Universal | | | | |
| | or 2967-042A Titan Residue Manager for JD Coulters | 8 | 12 | 16 | 24 |
| | or 2967-115 (for use with 2960-015 coulters) | | | | |
| or 2967-070 (Quick adjust) Optional | | | | | |
| FRAME MOUNTED COULTERS ONLY | 2999-101 (basic coulters ass'y)** Choice of blade | 4 | 6 | N.A. | N.A. |
| | Order 2990-161/2990-158, 3010-303 & blade | 4 | 6 | N.A. | N.A. |

** See the price book for blade choices.

JD 1770 & 1775 FRONT FOLD PLANTER (12 Row to 24 Row)

JD 7200 FLEX FOLD PLANTER (8 Row Wide - 24 Row Narrow)

JD 7200 RIGID FOLD PLANTER (12 Row Narrow)

| Combination of Coulters | | Quantity to order for each planter | | | |
|--|--|------------------------------------|--------|--------|--------|
| | | 8 R W | 12 R N | 16 R N | 24 R N |
| <i>Model No.'s to Order for each planter configuration</i> | | | | | |
| DOUBLE COULTERS | | | | | |
| 2 LIQUID FERT. COULTERS ONLY | | | | | |
| NOT AVAILABLE | | N.A. | N.A. | N.A. | N.A. |
| 1 DRY / 1 LIQUID FERT. COULTERS ONLY | | | | | |
| NOT AVAILABLE | | N.A. | N.A. | N.A. | N.A. |
| 1 NO-TILL / 1 FERT. COULTER ONLY | | | | | |
| NOT AVAILABLE | | N.A. | N.A. | N.A. | N.A. |
| 2 NO-TILL COULTER ONLY | | | | | |
| NOT AVAILABLE | | N.A. | N.A. | N.A. | N.A. |

** See the price book for blade choices.

**** The Clean Up Crew and Unit Mounted Coulters cannot be used together, with the exception of the 2967-115, if using the 2967-115 combination in conjunction with Frame Mounted Fertilizer Coulters, Fertilizer Coulters can only be mounted 4" or farther from the row.

Continued on pg 30

JD 1770 & 1775 FRONT FOLD PLANTER (12 Row to 24 Row)
JD 7200 FLEX FOLD PLANTER (8 Row Wide - 24 Row Narrow)
JD 7200 RIGID FOLD PLANTER (12 Row Narrow)

| Combination of Coulters | | Quantity to order for each planter | | | |
|---|--|------------------------------------|--------|---------|--------|
| | | 8 R W | 12 R N | 16 R N | 24 R N |
| <i>Model No.'s to Order for each planter configuration</i> | | | | | |
| 1 LIQUID FERTILIZER AND COMBO UNIT ONLY | 2995-065-R [^] order 2990-158 3010-303 and choice of blade | 4 | 6 | | |
| | 2995-065-R (3" x 7") [^] order 2990-161 & 3010-303 and choice of blade | 4 | 6 | | |
| | 2995-065-L/R [^] order 2990-154 & 2990-310 and choice of blade | | | 8 and 8 | N.A. |
| | 2975-128 (front bar kit) | | | 1 | |
| | 2975-189 (set back) Required | 8 | 12 | 16 | N.A. |
| or 2960-034 Coulters w/ U.N.T. bracket** 2960-127 (coulters only)** | 8 | 12 | 16 | N.A. | |
| 2967-007 U.N.T. Residue Manager kit or 2967-035 Titan Universal or 2967-042A Titan Residue Manager for JD Coulters or 2967-115 (for use with 2960-015) | 8 | 12 | 16 | 24 | |
| 2960-034 Coulters w/ U.N.T. bracket** See below or 2960-127 (coulters only)** | 8 | 12 | 16 | 24 | |
| 1 JD LIQUID FERTILIZER AND COMBO UNIT ONLY | 2967-007 U.N.T. Residue Manager kit or 2967-035 Titan Universal or 2967-042A Titan Residue Manager for JD Coulters or 2967-115 (for use with 2960-015)**** 2967-070 (Quick adjust) 2975-189 (set back) Required | 8 | 12 | 16 | 24 |

** See the price book for blade choices.

**** The Clean Up Crew and Unit Mounted Coulters cannot be used together, with the exception of the 2967-115, if using the 2967-115 combination in conjunction with Frame Mounted Fertilizer Coulters, Fertilizer Coulters can only be mounted 4" or farther from the row.