JD 1760 WING FLEX FOLD PLANTER

Equipped with no options

Model No's to Order for each planter configuration		Quantity to order for each planter	
		8 R	**12 R**
Unit Mounted Liquid Fertilizer Coulter	2995-014 and 2995-015 T.O.W opener (no bar kit required)	**8**	**12**
	or 2959-003 (2" offset fert. injection)		
	2967-180 (Residue Manager for 2959-003)	**8**	**12**
	or 2961-012 Cut-n-Feed		
	or 2962-001 and 2962-002 RUMDDFO		
	or 2963-001 L & R Challenger		
	2975-189 (Set back bracket) Required	**2**	**2**
2960 UNIT MOUNTED CONSERVATION COULTERS ONLY	2960-032 Unit Coulter		
	2960-034 Coulter w/ U.N.T. bracket		
	2960-127 (coulter only)*	**8**	**12**
	2960-126 Spring Kit	**N/A**	**N/A**
CLEAN UP CREW ONLY	2965-015 (12" solid blade)		
	or 2965-020 (13" notched blade)		
	or 2965-022 Screw Adjust Trashmaster		
	or 2967-009 Screw adjust residue manager UNT (long arm)		
	or 2967-013 Short Narrow U.N.T.		
	or 2967-015 (13" steel wheel)	**8**	**12**
	or 2967-029 Short U.N.T.		
	or 2967-048 Narrow Row Unit Mounted Residue Manager		
	or 2967-049 Screw Adjust Short UNT		
	or 2967-052 Screw Adjust		
	or 2967-054 Narrow row Screw Adjust		
	or 2967-081 R.M. attachment for JD tool hanger		
	or 2967-092 L & R Notched disc, for J D tool hanger		
	or 2967-093 L & R Notched disc screw adjust		
	or 2967-094 L & R Notched disc, universal mount		
Combination Attachments	2961-010 Cut-n-Move		
	or 2967-007 U.N.T. Residue Manager Kit	**8**	**12**
	or 2967-035 Titan Universal		
	or 2967-042 Titan Residue Manager for JD Coulter		
	or 2967-043 Titan Screw adjust residue manager for JD Coulter		
	or 2967-051 For use with JD Coulter		
	or 2967-115 (for use with 2960-127 coulter)		
	2967-070 (Quick adjust) Optional		

*Blade Choices refer to price book.